





- de** Installationsanleitung
- en** Installation Instructions
- fr** Instructions d'installation
- it** Istruzioni di montaggio
- nl** Installatiehandleiding
- es** Instrucciones de Instalación
- pt** Instruções de instalação
- da** Installationsvejledning
- sv** Installation anvisningar

- fi** Asennusohje
- pl** Instrukcja instalacji
- cs** Návod k instalaci
- sk** Návod na montáž
- el** Οδηγίες εγκατάστασης
- sl** Navodila za instalacijo
- hu** Beépítési útmutató
- ru** Руководство по установке
- tr** Montaj talimatı




1




2348Z01

2



2348Z02



3



2348Z03


4

2348Z04




5

- 1 DC 12 V (G+)
- 2 GND (CL-)
- 3 BSB (CL+)



6



<http://siemens.com/bt/download>
 Search: **QAA74..**
 Filter: **your language**

