

Halter 39 x 20 x 238 mm - Platin

ERSATZTEILE

04 17 20 014 00



|                                                                                   |                         |                    |
|-----------------------------------------------------------------------------------|-------------------------|--------------------|
|  | Platin                  | 04 17 20 014 00-08 |
|  | Chrom                   | 04 17 20 014 00-00 |
|  | Platin gebürstet        | 04 17 20 014 00-06 |
|  | Messing (23kt Gold)     | 04 17 20 014 00-09 |
|  | Dark Chrome             | 04 17 20 014 00-19 |
|  | Bronze gebürstet        | 04 17 20 014 00-42 |
|  | Chrom gebürstet         | 04 17 20 014 00-93 |
|  | Dark Platinum gebürstet | 04 17 20 014 00-99 |



## Halter 39 x 20 x 238 mm - Platin

ERSATZTEILE

04 17 20 014 00



## Halter 39 x 20 x 238 mm - Platin

ERSATZTEILE

04 17 20 014 00