












04 20 36 002 08



	Chrom	04 20 36 002 08-00
	Gold (23,9kt)	04 20 36 002 08-01
	Platin gebürstet	04 20 36 002 08-06
	Platin	04 20 36 002 08-08
	Messing (23kt Gold)	04 20 36 002 08-09
	weiß	04 20 36 002 08-12
	Dark Brass matt	04 20 36 002 08-16
	Dark Bronze matt	04 20 36 002 08-17
	Messing gebürstet (23kt Gold)	04 20 36 002 08-28
	Dark Platinum gebürstet	04 20 36 002 08-99



Griff Neutral - Chrom

ERSATZTEILE

04 20 36 002 08



Griff Neutral - Chrom

ERSATZTEILE

04 20 36 002 08