

04 20 36 002 08



|                                                                                    |                               |                    |
|------------------------------------------------------------------------------------|-------------------------------|--------------------|
|   | Platin gebürstet              | 04 20 36 002 08-06 |
|   | Chrom                         | 04 20 36 002 08-00 |
|   | Gold (23,9kt)                 | 04 20 36 002 08-01 |
|   | Platin                        | 04 20 36 002 08-08 |
|   | Messing (23kt Gold)           | 04 20 36 002 08-09 |
|   | weiß                          | 04 20 36 002 08-12 |
|   | Dark Brass matt               | 04 20 36 002 08-16 |
|   | Dark Bronze matt              | 04 20 36 002 08-17 |
|   | Messing gebürstet (23kt Gold) | 04 20 36 002 08-28 |
|  | Dark Platinum gebürstet       | 04 20 36 002 08-99 |



## Griff Neutral - Platin gebürstet

ERSATZTEILE

04 20 36 002 08



## Griff Neutral - Platin gebürstet

ERSATZTEILE

04 20 36 002 08