


Zugstange für Ablaufgarnitur mit Knopf Ø 30 x 200 mm - Chrom

ERSATZTEILE

04 20 36 030 10



	Chrom	04 20 36 030 10-00
	Gold (23,9kt)	04 20 36 030 10-01
	bronze	04 20 36 030 10-02
	altmessing	04 20 36 030 10-03
	Platin gebürstet	04 20 36 030 10-06
	Platin	04 20 36 030 10-08
	Messing (23kt Gold)	04 20 36 030 10-09
	weiß	04 20 36 030 10-12



Zugstange für Ablaufgarnitur mit Knopf Ø 30 x 200 mm - Chrom

ERSATZTEILE

04 20 36 030 10



Zugstange für Ablaufgarnitur mit Knopf Ø 30 x 200 mm - Chrom

ERSATZTEILE

04 20 36 030 10