

Zugstange für Ablaufgarnitur mit Knopf Ø 4 x 400 mm - Chrom gebürstet

ERSATZTEILE

04 20 62 030 80



	Chrom gebürstet	04 20 62 030 80-93
	Chrom	04 20 62 030 80-00
	Gold (23,9kt)	04 20 62 030 80-01
	chrom gebürstet (04)	04 20 62 030 80-04
	Platin gebürstet	04 20 62 030 80-06
	Platin	04 20 62 030 80-08
	Messing (23kt Gold)	04 20 62 030 80-09
	Gold gebürstet (23,9kt)	04 20 62 030 80-14
	Schwarz matt	04 20 62 030 80-33
	Cyprum	04 20 62 030 80-49



Zugstange für Ablaufgarnitur mit Knopf Ø 4 x 400 mm - Chrom gebürstet

ERSATZTEILE

04 20 62 030 80



Zugstange für Ablaufgarnitur mit Knopf Ø 4 x 400 mm - Chrom gebürstet

ERSATZTEILE

04 20 62 030 80