













04 20 88 052 00



	Schwarz matt	04 20 88 052 00-33
	Chrom	04 20 88 052 00-00
	Platin gebürstet	04 20 88 052 00-06
	Platin	04 20 88 052 00-08
	Weiß matt	04 20 88 052 00-10
	Dark Brass matt	04 20 88 052 00-16
	Dark Bronze matt	04 20 88 052 00-17
	Dark Chrome	04 20 88 052 00-19
	Light Gold gebürstet	04 20 88 052 00-27
	Messing gebürstet (23kt Gold)	04 20 88 052 00-28
	Dark Brass gebürstet	04 20 88 052 00-39
	Bronze gebürstet	04 20 88 052 00-42
	Champagne gebürstet (22kt Gold)	04 20 88 052 00-46
	Champagne (22kt Gold)	04 20 88 052 00-47
	Cyprum	04 20 88 052 00-49
	Chrom gebürstet	04 20 88 052 00-93
	Dark Platinum gebürstet	04 20 88 052 00-99



Griff Hebel 106 x 48,5 x 37 mm - Schwarz matt

ERSATZTEILE

04 20 88 052 00



Griff Hebel 106 x 48,5 x 37 mm - Schwarz matt

ERSATZTEILE

04 20 88 052 00