

















04 20 89 010 00



	Cyprum	04 20 89 010 00-49
	Chrom	04 20 89 010 00-00
	Platin gebürstet	04 20 89 010 00-06
	Platin	04 20 89 010 00-08
	Messing (23kt Gold)	04 20 89 010 00-09
	Weiß matt	04 20 89 010 00-10
	schwarz	04 20 89 010 00-13
	Dark Brass matt	04 20 89 010 00-16
	Dark Bronze matt	04 20 89 010 00-17
	Dark Chrome	04 20 89 010 00-19
	Messing gebürstet (23kt Gold)	04 20 89 010 00-28
	Schwarz matt	04 20 89 010 00-33
	Champagne gebürstet (22kt Gold)	04 20 89 010 00-46
	Champagne (22kt Gold)	04 20 89 010 00-47
	Dark Platinum gebürstet	04 20 89 010 00-99



Griff 70 x 70 x 43 mm - Cyprum

ERSATZTEILE

04 20 89 010 00



Griff 70 x 70 x 43 mm - Cyprum

ERSATZTEILE

04 20 89 010 00