

04 20 89 011 00



	Weiß matt	04 20 89 011 00-10
	Chrom	04 20 89 011 00-00
	Platin gebürstet	04 20 89 011 00-06
	Platin	04 20 89 011 00-08
	Messing (23kt Gold)	04 20 89 011 00-09
	Schwarz	04 20 89 011 00-13
	Messing gebürstet (23kt Gold)	04 20 89 011 00-28
	Rot	04 20 89 011 00-29
	Schwarz matt	04 20 89 011 00-33



Griff 70 x 70 x 43 mm - Weiß matt

ERSATZTEILE

04 20 89 011 00



Griff 70 x 70 x 43 mm - Weiß matt

ERSATZTEILE

04 20 89 011 00