

Zugstange für Ablaufgarnitur mit Knopf 17 x 158 x 7 mm - Platin

ERSATZTEILE

04 20 89 030 80



	Platin	04 20 89 030 80-08
	Chrom	04 20 89 030 80-00
	Platin gebürstet	04 20 89 030 80-06
	Messing (23kt Gold)	04 20 89 030 80-09
	Weiß matt	04 20 89 030 80-10
	schwarz	04 20 89 030 80-13
	Dark Brass matt	04 20 89 030 80-16
	Dark Bronze matt	04 20 89 030 80-17
	Dark Chrome	04 20 89 030 80-19
	Light Gold gebürstet	04 20 89 030 80-27
	Messing gebürstet (23kt Gold)	04 20 89 030 80-28
	Rot	04 20 89 030 80-29
	Schwarz matt	04 20 89 030 80-33
	Dark Brass gebürstet	04 20 89 030 80-39
	Bronze gebürstet	04 20 89 030 80-42
	Champagne gebürstet (22kt Gold)	04 20 89 030 80-46
	Champagne (22kt Gold)	04 20 89 030 80-47
	Cyprum	04 20 89 030 80-49
	Chrom gebürstet	04 20 89 030 80-93
	Dark Platinum gebürstet	04 20 89 030 80-99



Zugstange für Ablaufgarnitur mit Knopf 17 x 158 x 7 mm - Platin

ERSATZTEILE

04 20 89 030 80



Zugstange für Ablaufgarnitur mit Knopf 17 x 158 x 7 mm - Platin

ERSATZTEILE

04 20 89 030 80