







04 24 04 074 00



	Chrom	04 24 04 074 00-00
	chrom gebürstet (04)	04 24 04 074 00-04
	Platin gebürstet	04 24 04 074 00-06
	Platin	04 24 04 074 00-08
	Messing (23kt Gold)	04 24 04 074 00-09



04 24 04 074 00



04 24 04 074 00