

# Bogen 20° 55 x 40 x 23 mm - Champagne (22kt Gold)

## ERSATZTEILE

04 24 04 189 00



|                                                                                     |                                 |                    |
|-------------------------------------------------------------------------------------|---------------------------------|--------------------|
|    | Champagne (22kt Gold)           | 04 24 04 189 00-47 |
|    | Chrom                           | 04 24 04 189 00-00 |
|    | chrom gebürstet (04)            | 04 24 04 189 00-04 |
|    | Platin gebürstet                | 04 24 04 189 00-06 |
|    | Platin                          | 04 24 04 189 00-08 |
|    | Messing (23kt Gold)             | 04 24 04 189 00-09 |
|    | Weiß matt                       | 04 24 04 189 00-10 |
|    | schwarz                         | 04 24 04 189 00-13 |
|   | Dark Brass matt                 | 04 24 04 189 00-16 |
|  | Dark Bronze matt                | 04 24 04 189 00-17 |
|  | Dark Chrome                     | 04 24 04 189 00-19 |
|  | Light Gold gebürstet            | 04 24 04 189 00-27 |
|  | Messing gebürstet (23kt Gold)   | 04 24 04 189 00-28 |
|  | Schwarz matt                    | 04 24 04 189 00-33 |
|  | Dark Brass gebürstet            | 04 24 04 189 00-39 |
|  | Bronze gebürstet                | 04 24 04 189 00-42 |
|  | Champagne gebürstet (22kt Gold) | 04 24 04 189 00-46 |
|  | Cyprum                          | 04 24 04 189 00-49 |
|  | Chrom gebürstet                 | 04 24 04 189 00-93 |
|  | Dark Platinum gebürstet         | 04 24 04 189 00-99 |



Bogen 20° 55 x 40 x 23 mm - Champagne (22kt Gold)

ERSATZTEILE

04 24 04 189 00



Bogen 20° 55 x 40 x 23 mm - Champagne (22kt Gold)

ERSATZTEILE

04 24 04 189 00