























04 27 01 015 00



	Chrom	04 27 01 015 00-00
	Gold (23,9kt)	04 27 01 015 00-01
	bronze	04 27 01 015 00-02
	chrom gebürstet (04)	04 27 01 015 00-04
	Platin gebürstet	04 27 01 015 00-06
	Platin	04 27 01 015 00-08
	Messing (23kt Gold)	04 27 01 015 00-09
	weiß	04 27 01 015 00-12
	schwarz	04 27 01 015 00-13
	Gold gebürstet (23,9kt)	04 27 01 015 00-14
	Dark Brass matt	04 27 01 015 00-16
	Dark Bronze matt	04 27 01 015 00-17
	Messing gebürstet (23kt Gold)	04 27 01 015 00-28
	Rot	04 27 01 015 00-29
	Orange	04 27 01 015 00-30
		04 27 01 015 00-32
	Schwarz matt	04 27 01 015 00-33
	Platin / Platin gebürstet	04 27 01 015 00-36
	chrom satin	04 27 01 015 00-41
	Champagne (22kt Gold)	04 27 01 015 00-47
	Dark Platin gebürstet	04 27 01 015 00-99



Rosette 80 x 80 x 19 mm - Chrom

ERSATZTEILE

04 27 01 015 00



Rosette 80 x 80 x 19 mm - Chrom

ERSATZTEILE

04 27 01 015 00