









04 27 98 021 00



	Chrom	04 27 98 021 00-00
	Platin gebürstet	04 27 98 021 00-06
	Platin	04 27 98 021 00-08
	Dark Brass matt	04 27 98 021 00-16
	Dark Bronze matt	04 27 98 021 00-17
	Messing gebürstet (23kt Gold)	04 27 98 021 00-28
	Cyprum	04 27 98 021 00-49
	Dark Platinum gebürstet	04 27 98 021 00-99



Rosette mit Symbolen 60 x 60 x 28 mm - Chrom

ERSATZTEILE

04 27 98 021 00



Rosette mit Symbolen 60 x 60 x 28 mm - Chrom

ERSATZTEILE

04 27 98 021 00