


04 27 98 026 05



	Chrom	04 27 98 026 05-00
	Platin gebürstet	04 27 98 026 05-06
	Platin	04 27 98 026 05-08
	Messing gebürstet (23kt Gold)	04 27 98 026 05-28
	Champagne (22kt Gold)	04 27 98 026 05-47
	Dark Platinum gebürstet	04 27 98 026 05-99



Bedienelement 60 x 60 x 72 mm - Chrom

ERSATZTEILE

04 27 98 026 05



Bedienelement 60 x 60 x 72 mm - Chrom

ERSATZTEILE

04 27 98 026 05

04 27 98 026 05

Ersatzteile für die
anderen
Oberflächenvarianten
finden Sie hier: Platin
gebürstet

