








04 31 09 031 00



	Chrom	04 31 09 031 00-00
	Platin	04 31 09 031 00-08
	Messing (23kt Gold)	04 31 09 031 00-09
	Gold gebürstet (23,9kt)	04 31 09 031 00-14
	Rot	04 31 09 031 00-29
	Schwarz matt	04 31 09 031 00-33
	Platin / Platin gebürstet	04 31 09 031 00-36



Zugstange für Umstellung Ø 15 x 244 mm - Chrom

ERSATZTEILE

04 31 09 031 00



Zugstange für Umstellung Ø 15 x 244 mm - Chrom

ERSATZTEILE

04 31 09 031 00