

Stopfen für Ab- und Überlaufgarnitur 100 x 70 x 68 mm - Platin

ERSATZTEILE

04 31 20 031 48



	Platin	04 31 20 031 48-08
	Chrom	04 31 20 031 48-00
	Gold (23,9kt)	04 31 20 031 48-01
	bronze	04 31 20 031 48-02
	chrom gebürstet (04)	04 31 20 031 48-04
	chrom edelmatt	04 31 20 031 48-05
	Platin gebürstet	04 31 20 031 48-06
	Messing (23kt Gold)	04 31 20 031 48-09
	Weiß matt	04 31 20 031 48-10
	weiß	04 31 20 031 48-12
	schwarz	04 31 20 031 48-13
	Gold gebürstet (23,9kt)	04 31 20 031 48-14
	rot (15)	04 31 20 031 48-15
	Dark Brass matt	04 31 20 031 48-16
	Dark Bronze matt	04 31 20 031 48-17
	Light Gold	04 31 20 031 48-26
	Light Gold gebürstet	04 31 20 031 48-27
	Messing gebürstet (23kt Gold)	04 31 20 031 48-28
	Rot	04 31 20 031 48-29
	Orange	04 31 20 031 48-30
	Dunkelgrün	04 31 20 031 48-31
		04 31 20 031 48-32
	Schwarz matt	04 31 20 031 48-33
	Platin / Platin gebürstet	04 31 20 031 48-36
	Dark Brass gebürstet	04 31 20 031 48-39
	chrom satin	04 31 20 031 48-41
	Bronze gebürstet	04 31 20 031 48-42

Stopfen für Ab- und Überlaufgarnitur 100 x 70 x 68 mm - Platin

ERSATZTEILE

04 31 20 031 48

	Champagne gebürstet (22kt Gold)	04 31 20 031 48-46
	Champagne (22kt Gold)	04 31 20 031 48-47
	Cyprum	04 31 20 031 48-49
	Chrom gebürstet	04 31 20 031 48-93
	Dark Platinum gebürstet	04 31 20 031 48-99



Stopfen für Ab- und Überlaufgarnitur 100 x 70 x 68 mm - Platin

ERSATZTEILE

04 31 20 031 48