


Halter für Papierrollenhalter ohne Deckel 31,5 x 14 x 40 mm - Chrom

ERSATZTEILE

05 17 89 552 00



	Chrom	05 17 89 552 00-00
	Platin gebürstet	05 17 89 552 00-06
	Platin	05 17 89 552 00-08
	Weiß matt	05 17 89 552 00-10
	Dark Brass matt	05 17 89 552 00-16
	Dark Bronze matt	05 17 89 552 00-17
	Dark Chrome	05 17 89 552 00-19
	Light Gold gebürstet	05 17 89 552 00-27
	Messing gebürstet (23kt Gold)	05 17 89 552 00-28
	Schwarz matt	05 17 89 552 00-33
	Dark Brass gebürstet	05 17 89 552 00-39
	Bronze gebürstet	05 17 89 552 00-42
	Champagne gebürstet (22kt Gold)	05 17 89 552 00-46
	Champagne (22kt Gold)	05 17 89 552 00-47
	Chrom gebürstet	05 17 89 552 00-93
	Dark Platinum gebürstet	05 17 89 552 00-99



Halter für Papierrollenhalter ohne Deckel 31,5 x 14 x 40 mm - Chrom

ERSATZTEILE

05 17 89 552 00



Halter für Papierrollenhalter ohne Deckel 31,5 x 14 x 40 mm - Chrom

ERSATZTEILE

05 17 89 552 00