














05 17 97 561 01



	Chrom	05 17 97 561 01-00
	Platin gebürstet	05 17 97 561 01-06
	Dark Chrome	05 17 97 561 01-19
	Light Gold	05 17 97 561 01-26
	Light Gold gebürstet	05 17 97 561 01-27
	Schwarz matt	05 17 97 561 01-33
	Dark Brass gebürstet	05 17 97 561 01-39
	Bronze gebürstet	05 17 97 561 01-42
	Champagne gebürstet (22kt Gold)	05 17 97 561 01-46
	Champagne (22kt Gold)	05 17 97 561 01-47
	Chrom gebürstet	05 17 97 561 01-93
	Dark Platinum gebürstet	05 17 97 561 01-99



Halter für Papierrollenhalter ohne Deckel 31 x 13 x 40 mm - Chrom

ERSATZTEILE

05 17 97 561 01



Halter für Papierrollenhalter ohne Deckel 31 x 13 x 40 mm - Chrom

ERSATZTEILE

05 17 97 561 01