


05 20 97 500 00



	Chrom	05 20 97 500 00-00
	Platin gebürstet	05 20 97 500 00-06
	Platin	05 20 97 500 00-08
	Messing (23kt Gold)	05 20 97 500 00-09



Griff für Stand-Accessoires 80 x 38 x 14 mm - Chrom

ERSATZTEILE

05 20 97 500 00



Griff für Stand-Accessoires 80 x 38 x 14 mm - Chrom

ERSATZTEILE

05 20 97 500 00