


Halter für Seifenschale 60 x 34 x 20 mm - Platin

ERSATZTEILE

08 17 30 502



	Platin	08 17 30 502-08
	Chrom	08 17 30 502-00
	Platin gebürstet	08 17 30 502-06
	Messing (23kt Gold)	08 17 30 502-09
	Weiß matt	08 17 30 502-10
	Dark Brass matt	08 17 30 502-16
	Dark Bronze matt	08 17 30 502-17
	Dark Chrome	08 17 30 502-19
	Light Gold	08 17 30 502-26
	Light Gold gebürstet	08 17 30 502-27
	Messing gebürstet (23kt Gold)	08 17 30 502-28
	Schwarz matt	08 17 30 502-33
	Dark Brass gebürstet	08 17 30 502-39
	Bronze gebürstet	08 17 30 502-42
	Champagne gebürstet (22kt Gold)	08 17 30 502-46
	Champagne (22kt Gold)	08 17 30 502-47
	Chrom gebürstet	08 17 30 502-93
	Dark Platinum gebürstet	08 17 30 502-99



Halter für Seifenschale 60 x 34 x 20 mm - Platin

ERSATZTEILE

08 17 30 502



Halter für Seifenschale 60 x 34 x 20 mm - Platin

ERSATZTEILE

08 17 30 502