

Seifenschale Ø 120 x 20 mm - Chrom

ERSATZTEILE

08 17 97 570



	Chrom	08 17 97 570-00
	Platin gebürstet	08 17 97 570-06
	Platin	08 17 97 570-08
	Messing (23kt Gold)	08 17 97 570-09
	Weiß matt	08 17 97 570-10
	Dark Brass matt	08 17 97 570-16
	Dark Bronze matt	08 17 97 570-17
	Dark Chrome	08 17 97 570-19
	Light Gold	08 17 97 570-26
	Light Gold gebürstet	08 17 97 570-27
	Messing gebürstet (23kt Gold)	08 17 97 570-28
	Schwarz matt	08 17 97 570-33
	Dark Brass gebürstet	08 17 97 570-39
	Bronze gebürstet	08 17 97 570-42
	Champagne gebürstet (22kt Gold)	08 17 97 570-46
	Champagne (22kt Gold)	08 17 97 570-47
	Chrom gebürstet	08 17 97 570-93
	Dark Platinum gebürstet	08 17 97 570-99



Seifenschale Ø 120 x 20 mm - Chrom

ERSATZTEILE

08 17 97 570



Seifenschale Ø 120 x 20 mm - Chrom

ERSATZTEILE

08 17 97 570