


Rosette Ø 40 x 11 mm - Schwarz matt

ERSATZTEILE

08 27 97 501



	Schwarz matt	08 27 97 501-33
	Chrom	08 27 97 501-00
	Platin gebürstet	08 27 97 501-06
	Dark Brass matt	08 27 97 501-16
	Dark Bronze matt	08 27 97 501-17
	Dark Chrome	08 27 97 501-19
	Light Gold	08 27 97 501-26
	Light Gold gebürstet	08 27 97 501-27
	Messing gebürstet (23kt Gold)	08 27 97 501-28
	Bronze gebürstet	08 27 97 501-42
	Champagne gebürstet (22kt Gold)	08 27 97 501-46
	Champagne (22kt Gold)	08 27 97 501-47
	Chrom gebürstet	08 27 97 501-93
	Dark Platinum gebürstet	08 27 97 501-99



Rosette Ø 40 x 11 mm - Schwarz matt

ERSATZTEILE

08 27 97 501



Rosette Ø 40 x 11 mm - Schwarz matt

ERSATZTEILE

08 27 97 501