


Zugknopf für Ablaufgarnitur Ø 15 x 37 mm - Chrom

ERSATZTEILE

09 20 01 040



	Chrom	09 20 01 040-00
	Gold (23,9kt)	09 20 01 040-01
	chrom gebürstet (04)	09 20 01 040-04
	Platin gebürstet	09 20 01 040-06
	Platin	09 20 01 040-08
	Messing (23kt Gold)	09 20 01 040-09
	Weiß matt	09 20 01 040-10
	Dark Brass matt	09 20 01 040-16
	Dark Bronze matt	09 20 01 040-17
	Dark Chrome	09 20 01 040-19
	Light Gold	09 20 01 040-26
	Light Gold gebürstet	09 20 01 040-27
	Messing gebürstet (23kt Gold)	09 20 01 040-28
	Schwarz matt	09 20 01 040-33
	Dark Brass gebürstet	09 20 01 040-39
	chrom satin	09 20 01 040-41
	Bronze gebürstet	09 20 01 040-42
	Champagne gebürstet (22kt Gold)	09 20 01 040-46
	Champagne (22kt Gold)	09 20 01 040-47
	Cyprum	09 20 01 040-49
	Chrom gebürstet	09 20 01 040-93
	Dark Platinum gebürstet	09 20 01 040-99



Zugknopf für Ablaufgarnitur Ø 15 x 37 mm - Chrom

ERSATZTEILE

09 20 01 040



Zugknopf für Ablaufgarnitur Ø 15 x 37 mm - Chrom

ERSATZTEILE

09 20 01 040