


Zugknopf Ø 24 x 18 mm - Messing (23kt Gold)

ERSATZTEILE

09 20 24 031



	Messing (23kt Gold)	09 20 24 031-09
	Chrom	09 20 24 031-00
	Gold (23,9kt)	09 20 24 031-01
	Platin gebürstet	09 20 24 031-06
	Platin	09 20 24 031-08
	Dark Brass matt	09 20 24 031-16
	Dark Bronze matt	09 20 24 031-17
	Dark Brass gebürstet	09 20 24 031-39
	Bronze gebürstet	09 20 24 031-42
	Dark Platinum gebürstet	09 20 24 031-99



Zugknopf Ø 24 x 18 mm - Messing (23kt Gold)

ERSATZTEILE

09 20 24 031



Zugknopf Ø 24 x 18 mm - Messing (23kt Gold)

ERSATZTEILE

09 20 24 031