


# Zugknopf Ø 45 x 10 mm - Chrom gebürstet

## ERSATZTEILE

09 20 62 031



|                                                                                     |                                 |                 |
|-------------------------------------------------------------------------------------|---------------------------------|-----------------|
|    | Chrom gebürstet                 | 09 20 62 031-93 |
|    | Chrom                           | 09 20 62 031-00 |
|    | chrom gebürstet (04)            | 09 20 62 031-04 |
|    | Platin gebürstet                | 09 20 62 031-06 |
|    | Dark Chrome                     | 09 20 62 031-19 |
|    | Light Gold                      | 09 20 62 031-26 |
|    | Light Gold gebürstet            | 09 20 62 031-27 |
|    | Schwarz matt                    | 09 20 62 031-33 |
|    | Dark Brass gebürstet            | 09 20 62 031-39 |
|   | Bronze gebürstet                | 09 20 62 031-42 |
|  | Champagne gebürstet (22kt Gold) | 09 20 62 031-46 |
|  | Champagne (22kt Gold)           | 09 20 62 031-47 |
|  | Dark Platinum gebürstet         | 09 20 62 031-99 |



## Zugknopf Ø 45 x 10 mm - Chrom gebürstet

ERSATZTEILE

09 20 62 031



## Zugknopf Ø 45 x 10 mm - Chrom gebürstet

ERSATZTEILE

09 20 62 031