

09 20 74 007



	Chrom	09 20 74 007-00
	Platin gebürstet	09 20 74 007-06
	Platin	09 20 74 007-08
	Dark Brass matt	09 20 74 007-16
	Dark Bronze matt	09 20 74 007-17
	Messing gebürstet (23kt Gold)	09 20 74 007-28
	Schwarz matt	09 20 74 007-33
	Cyprum	09 20 74 007-49
	Chrom gebürstet	09 20 74 007-93
	Dark Platinum gebürstet	09 20 74 007-99



Griff für Umstellung Ø 60 x 29 mm - Chrom

ERSATZTEILE

09 20 74 007



Griff für Umstellung Ø 60 x 29 mm - Chrom

ERSATZTEILE

09 20 74 007