


Zugknopf 18,5 x 24 x 18 mm - Platin

ERSATZTEILE

09 20 78 030



	Platin	09 20 78 030-08
	Chrom	09 20 78 030-00
	Platin gebürstet	09 20 78 030-06
	Messing (23kt Gold)	09 20 78 030-09
	Dark Brass matt	09 20 78 030-16
	Dark Bronze matt	09 20 78 030-17
	Dark Chrome	09 20 78 030-19
	Light Gold gebürstet	09 20 78 030-27
	Messing gebürstet (23kt Gold)	09 20 78 030-28
	Schwarz matt	09 20 78 030-33
	Dark Brass gebürstet	09 20 78 030-39
	Bronze gebürstet	09 20 78 030-42
	Champagne gebürstet (22kt Gold)	09 20 78 030-46
	Champagne (22kt Gold)	09 20 78 030-47
	Cyprum	09 20 78 030-49
	Chrom gebürstet	09 20 78 030-93
	Dark Platinum gebürstet	09 20 78 030-99



Zugknopf 18,5 x 24 x 18 mm - Platin

ERSATZTEILE

09 20 78 030



Zugknopf 18,5 x 24 x 18 mm - Platin

ERSATZTEILE

09 20 78 030