


Zugknopf Ø 37 x 22,5 mm - Chrom

ERSATZTEILE

09 20 80 016



	Chrom	09 20 80 016-00
	Platin gebürstet	09 20 80 016-06
	Platin	09 20 80 016-08
	Dark Brass matt	09 20 80 016-16
	Dark Bronze matt	09 20 80 016-17
	Light Gold gebürstet	09 20 80 016-27
	Messing gebürstet (23kt Gold)	09 20 80 016-28
	Dark Brass gebürstet	09 20 80 016-39
	Bronze gebürstet	09 20 80 016-42
	Champagne gebürstet (22kt Gold)	09 20 80 016-46
	Champagne (22kt Gold)	09 20 80 016-47
	Chrom gebürstet	09 20 80 016-93
	Dark Platinum gebürstet	09 20 80 016-99



Zugknopf Ø 37 x 22,5 mm - Chrom

ERSATZTEILE

09 20 80 016



Zugknopf Ø 37 x 22,5 mm - Chrom

ERSATZTEILE

09 20 80 016