


Zugknopf Ø 37 x 22,5 mm - Messing gebürstet (23kt Gold)

ERSATZTEILE

09 20 80 016



|                                                                                     |                                       |                 |
|-------------------------------------------------------------------------------------|---------------------------------------|-----------------|
|    | Messing gebürstet<br>(23kt Gold)      | 09 20 80 016-28 |
|    | Chrom                                 | 09 20 80 016-00 |
|    | Platin gebürstet                      | 09 20 80 016-06 |
|    | Platin                                | 09 20 80 016-08 |
|    | Dark Brass matt                       | 09 20 80 016-16 |
|    | Dark Bronze matt                      | 09 20 80 016-17 |
|    | Light Gold<br>gebürstet               | 09 20 80 016-27 |
|    | Dark Brass<br>gebürstet               | 09 20 80 016-39 |
|   | Bronze gebürstet                      | 09 20 80 016-42 |
|  | Champagne<br>gebürstet (22kt<br>Gold) | 09 20 80 016-46 |
|  | Champagne (22kt<br>Gold)              | 09 20 80 016-47 |
|  | Chrom gebürstet                       | 09 20 80 016-93 |
|  | Dark Platinum<br>gebürstet            | 09 20 80 016-99 |



## Zugknopf Ø 37 x 22,5 mm - Messing gebürstet (23kt Gold)

---

ERSATZTEILE

09 20 80 016



## Zugknopf Ø 37 x 22,5 mm - Messing gebürstet (23kt Gold)

---

ERSATZTEILE

09 20 80 016