


Zugknopf Ø 30 x 20 mm - Messing gebürstet (23kt Gold)

ERSATZTEILE

09 20 88 002



	Messing gebürstet (23kt Gold)	09 20 88 002-28
	Chrom	09 20 88 002-00
	chrom gebürstet (04)	09 20 88 002-04
	Platin gebürstet	09 20 88 002-06
	Platin	09 20 88 002-08
	Weiß matt	09 20 88 002-10
	Dark Brass matt	09 20 88 002-16
	Dark Bronze matt	09 20 88 002-17
	Dark Chrome	09 20 88 002-19
	Light Gold	09 20 88 002-26
	Light Gold gebürstet	09 20 88 002-27
	Schwarz matt	09 20 88 002-33
	Dark Brass gebürstet	09 20 88 002-39
	Bronze gebürstet	09 20 88 002-42
	Champagne gebürstet (22kt Gold)	09 20 88 002-46
	Champagne (22kt Gold)	09 20 88 002-47
	Cyprum	09 20 88 002-49
	Chrom gebürstet	09 20 88 002-93
	Dark Platinum gebürstet	09 20 88 002-99



Zugknopf Ø 30 x 20 mm - Messing gebürstet (23kt Gold)

ERSATZTEILE

09 20 88 002



Zugknopf Ø 30 x 20 mm - Messing gebürstet (23kt Gold)

ERSATZTEILE

09 20 88 002