







Zugknopf für Ablaufgarnitur Ø 11,5 x 36 mm - Chrom

ERSATZTEILE

09 20 91 031



	Chrom	09 20 91 031-00
	Platin gebürstet	09 20 91 031-06
	Platin	09 20 91 031-08
	Messing (23kt Gold)	09 20 91 031-09
	Champagne (22kt Gold)	09 20 91 031-47



Zugknopf für Ablaufgarnitur Ø 11,5 x 36 mm - Chrom

ERSATZTEILE

09 20 91 031



Zugknopf für Ablaufgarnitur Ø 11,5 x 36 mm - Chrom

ERSATZTEILE

09 20 91 031