




















09 20 97 057



	Platin	09 20 97 057-08
	Chrom	09 20 97 057-00
	Platin gebürstet	09 20 97 057-06
	Weiß matt	09 20 97 057-10
	Dark Brass matt	09 20 97 057-16
	Dark Bronze matt	09 20 97 057-17
	Dark Chrome	09 20 97 057-19
	Light Gold	09 20 97 057-26
	Light Gold gebürstet	09 20 97 057-27
	Messing gebürstet (23kt Gold)	09 20 97 057-28
	Schwarz matt	09 20 97 057-33
	Dark Brass gebürstet	09 20 97 057-39
	Bronze gebürstet	09 20 97 057-42
	Champagne gebürstet (22kt Gold)	09 20 97 057-46
	Champagne (22kt Gold)	09 20 97 057-47
	Cyprum	09 20 97 057-49
	Chrom gebürstet	09 20 97 057-93
	Dark Platinum gebürstet	09 20 97 057-99



Griff für Drückergarnitur 90 x 30 x 12 mm - Platin

ERSATZTEILE

09 20 97 057



Griff für Drückergarnitur 90 x 30 x 12 mm - Platin

ERSATZTEILE

09 20 97 057