


Hebel 47 x 39 x 116 mm - Chrom

ERSATZTEILE

09 20 97 063



	Chrom	09 20 97 063-00
	Platin gebürstet	09 20 97 063-06
	Platin	09 20 97 063-08
	Dark Brass matt	09 20 97 063-16
	Dark Bronze matt	09 20 97 063-17
	Light Gold gebürstet	09 20 97 063-27
	Messing gebürstet (23kt Gold)	09 20 97 063-28
	Schwarz matt	09 20 97 063-33
	Champagne gebürstet (22kt Gold)	09 20 97 063-46
	Champagne (22kt Gold)	09 20 97 063-47
	Cyprum	09 20 97 063-49
	Chrom gebürstet	09 20 97 063-93
	Dark Platinum gebürstet	09 20 97 063-99



Hebel 47 x 39 x 116 mm - Chrom

ERSATZTEILE

09 20 97 063



Hebel 47 x 39 x 116 mm - Chrom

ERSATZTEILE

09 20 97 063