


Zugknopf Ø 32 x 10 mm - Champagne gebürstet (22kt Gold)

ERSATZTEILE

09 21 33 001



	Champagne gebürstet (22kt Gold)	09 21 33 001-46
	Chrom	09 21 33 001-00
	Gold (23,9kt)	09 21 33 001-01
	chrom gebürstet (04)	09 21 33 001-04
	chrom edelmatt	09 21 33 001-05
	Platin gebürstet	09 21 33 001-06
	Platin	09 21 33 001-08
	Messing (23kt Gold)	09 21 33 001-09
	Weiß matt	09 21 33 001-10
	weiß	09 21 33 001-12
	schwarz	09 21 33 001-13
	Gold gebürstet (23,9kt)	09 21 33 001-14
	Dark Brass matt	09 21 33 001-16
	Dark Bronze matt	09 21 33 001-17
	Dark Chrome	09 21 33 001-19
	Light Gold	09 21 33 001-26
	Light Gold gebürstet	09 21 33 001-27
	Messing gebürstet (23kt Gold)	09 21 33 001-28
	Rot	09 21 33 001-29
	Schwarz matt	09 21 33 001-33
	Platin / Platin gebürstet	09 21 33 001-36
	chrom satin	09 21 33 001-41
	Bronze gebürstet	09 21 33 001-42
	aluminium (45)	09 21 33 001-45
	Champagne (22kt Gold)	09 21 33 001-47
	cyprum matt	09 21 33 001-56

Zugknopf Ø 32 x 10 mm - Champagne gebürstet (22kt Gold)

ERSATZTEILE

09 21 33 001

	sand matt	09 21 33 001-72
	schwarz glänzend	09 21 33 001-76
	Chrom gebürstet	09 21 33 001-93
	Dark Platinum gebürstet	09 21 33 001-99



Zugknopf Ø 32 x 10 mm - Champagne gebürstet (22kt Gold)

ERSATZTEILE

09 21 33 001