

Rosette für Zugumstellung Ø 60 x 37 mm - Chrom

ERSATZTEILE

09 27 80 015



	Chrom	09 27 80 015-00
	Platin gebürstet	09 27 80 015-06
	Platin	09 27 80 015-08
	Dark Brass matt	09 27 80 015-16
	Dark Bronze matt	09 27 80 015-17
	Light Gold gebürstet	09 27 80 015-27
	Messing gebürstet (23kt Gold)	09 27 80 015-28
	Dark Brass gebürstet	09 27 80 015-39
	Bronze gebürstet	09 27 80 015-42
	Champagne gebürstet (22kt Gold)	09 27 80 015-46
	Champagne (22kt Gold)	09 27 80 015-47
	Chrom gebürstet	09 27 80 015-93
	Dark Platinum gebürstet	09 27 80 015-99



Rosette für Zugumstellung Ø 60 x 37 mm - Chrom

ERSATZTEILE

09 27 80 015



Rosette für Zugumstellung Ø 60 x 37 mm - Chrom

ERSATZTEILE

09 27 80 015