

09 27 97 013



	Chrom	09 27 97 013-00
	Platin gebürstet	09 27 97 013-06
	Platin	09 27 97 013-08
	Weiß matt	09 27 97 013-10
	Dark Brass matt	09 27 97 013-16
	Dark Bronze matt	09 27 97 013-17
	Dark Chrome	09 27 97 013-19
	Messing gebürstet (23kt Gold)	09 27 97 013-28
	Schwarz matt	09 27 97 013-33
	Dark Brass gebürstet	09 27 97 013-39
	Bronze gebürstet	09 27 97 013-42
	Champagne gebürstet (22kt Gold)	09 27 97 013-46
	Champagne (22kt Gold)	09 27 97 013-47
	Chrom gebürstet	09 27 97 013-93
	Dark Platin gebürstet	09 27 97 013-99



Rosette DB Logo Ø 50 x 10 mm, 3/4" - Chrom

ERSATZTEILE

09 27 97 013



Rosette DB Logo Ø 50 x 10 mm, 3/4" - Chrom

ERSATZTEILE

09 27 97 013