
























09 28 10 049



	Chrom	09 28 10 049-00
	Gold (23,9kt)	09 28 10 049-01
	chrom gebürstet (04)	09 28 10 049-04
	Platin gebürstet	09 28 10 049-06
	Platin	09 28 10 049-08
	Messing (23kt Gold)	09 28 10 049-09
	Weiß matt	09 28 10 049-10
	weiß	09 28 10 049-12
	schwarz	09 28 10 049-13
	Gold gebürstet (23,9kt)	09 28 10 049-14
	Dark Brass matt	09 28 10 049-16
	Dark Bronze matt	09 28 10 049-17
	Messing gebürstet (23kt Gold)	09 28 10 049-28
	Rot	09 28 10 049-29
	Orange	09 28 10 049-30
		09 28 10 049-32
	Schwarz matt	09 28 10 049-33
	Platin / Platin gebürstet	09 28 10 049-36
	chrom satin	09 28 10 049-41
	Champagne (22kt Gold)	09 28 10 049-47
	Cyprum	09 28 10 049-49
	Dark Platinum gebürstet	09 28 10 049-99



Rosette Ø 34 x 36,5 mm - Chrom

ERSATZTEILE

09 28 10 049



Rosette Ø 34 x 36,5 mm - Chrom

ERSATZTEILE

09 28 10 049