

09 28 10 111



	Chrom	09 28 10 111-00
	Platin gebürstet	09 28 10 111-06
	Platin	09 28 10 111-08
	Dark Brass matt	09 28 10 111-16
	Dark Bronze matt	09 28 10 111-17
	Messing gebürstet (23kt Gold)	09 28 10 111-28
	Schwarz matt	09 28 10 111-33
	Champagne gebürstet (22kt Gold)	09 28 10 111-46
	Champagne (22kt Gold)	09 28 10 111-47
	Chrom gebürstet	09 28 10 111-93
	Dark Platinum gebürstet	09 28 10 111-99



Rosette für Mischer Ø 55 x Ø 38,2 x 10 mm - Chrom

ERSATZTEILE

09 28 10 111



Rosette für Mischer Ø 55 x Ø 38,2 x 10 mm - Chrom

ERSATZTEILE

09 28 10 111