

# Rosette für Mischer Ø 55 x Ø 38,2 x 10 mm - Platin

## ERSATZTEILE

09 28 10 111



|                                                                                     |                                       |                 |
|-------------------------------------------------------------------------------------|---------------------------------------|-----------------|
|    | Platin                                | 09 28 10 111-08 |
|    | Chrom                                 | 09 28 10 111-00 |
|    | Platin gebürstet                      | 09 28 10 111-06 |
|    | Dark Brass matt                       | 09 28 10 111-16 |
|    | Dark Bronze matt                      | 09 28 10 111-17 |
|    | Messing gebürstet<br>(23kt Gold)      | 09 28 10 111-28 |
|    | Schwarz matt                          | 09 28 10 111-33 |
|    | Champagne<br>gebürstet (22kt<br>Gold) | 09 28 10 111-46 |
|    | Champagne (22kt<br>Gold)              | 09 28 10 111-47 |
|   | Chrom gebürstet                       | 09 28 10 111-93 |
|  | Dark Platinum<br>gebürstet            | 09 28 10 111-99 |



## Rosette für Mischer Ø 55 x Ø 38,2 x 10 mm - Platin

ERSATZTEILE

09 28 10 111



## Rosette für Mischer Ø 55 x Ø 38,2 x 10 mm - Platin

---

ERSATZTEILE

09 28 10 111