


Zugstange für Umstellung Ø 13 x 30,3 mm - Platin

ERSATZTEILE

09 31 09 139



	Platin	09 31 09 139-08
	Chrom	09 31 09 139-00
	chrom gebürstet (04)	09 31 09 139-04
	Platin gebürstet	09 31 09 139-06
	Weiß matt	09 31 09 139-10
	Dark Brass matt	09 31 09 139-16
	Dark Bronze matt	09 31 09 139-17
	Dark Chrome	09 31 09 139-19
	Light Gold	09 31 09 139-26
	Light Gold gebürstet	09 31 09 139-27
	Messing gebürstet (23kt Gold)	09 31 09 139-28
	Schwarz matt	09 31 09 139-33
	Dark Brass gebürstet	09 31 09 139-39
	Bronze gebürstet	09 31 09 139-42
	Champagne gebürstet (22kt Gold)	09 31 09 139-46
	Champagne (22kt Gold)	09 31 09 139-47
	Cyprum	09 31 09 139-49
	Soft Black	09 31 09 139-69
	Chrom gebürstet	09 31 09 139-93
	Dark Platinum gebürstet	09 31 09 139-99



Zugstange für Umstellung Ø 13 x 30,3 mm - Platin

ERSATZTEILE

09 31 09 139



Zugstange für Umstellung Ø 13 x 30,3 mm - Platin

ERSATZTEILE

09 31 09 139