

Auslauf - Messing gebürstet (23kt Gold)

ERSATZTEILE

90 11 70 011 00



	Messing gebürstet (23kt Gold)	90 11 70 011 00-28
	Chrom	90 11 70 011 00-00
	Platin gebürstet	90 11 70 011 00-06
	Dark Chrome	90 11 70 011 00-19
	Light Gold gebürstet	90 11 70 011 00-27
	Bronze gebürstet	90 11 70 011 00-42
	Dark Platinum gebürstet	90 11 70 011 00-99



Auslauf - Messing gebürstet (23kt Gold)

ERSATZTEILE

90 11 70 011 00



Auslauf - Messing gebürstet (23kt Gold)

ERSATZTEILE

90 11 70 011 00

90 11 70 011 00

Ersatzteile für die
anderen
Oberflächenvarianten
finden Sie hier:
Chrom

