


Griff für Unterputz Wand Neutral Hebel 60 x 60 x 40 mm - Messing gebürstet (23kt Gold)

ERSATZTEILE

90 20 70 057 06		
		Messing gebürstet (23kt Gold) 90 20 70 057 06-28
		Chrom 90 20 70 057 06-00
		Platin gebürstet 90 20 70 057 06-06
		Dark Chrome 90 20 70 057 06-19
		Light Gold gebürstet (PVD) 90 20 70 057 06-27
		Champagne gebürstet (22kt Gold) 90 20 70 057 06-46
		Champagne (22kt Gold) 90 20 70 057 06-47
		Dark Platinum gebürstet 90 20 70 057 06-99



Griff für Unterputz Wand Neutral Hebel 60 x 60 x 40 mm - Messing gebürstet
(23kt Gold)

ERSATZTEILE

90 20 70 057 06



Griff für Unterputz Wand Neutral Hebel 60 x 60 x 40 mm - Messing gebürstet
(23kt Gold)

ERSATZTEILE

90 20 70 057 06

**Griff für Unterputz Wand Neutral Hebel 60 x 60 x 40 mm - Messing gebürstet
(23kt Gold)**

ERSATZTEILE

90 20 70 057 06
Ersatzteile für die
anderen
Oberflächenvarianten
finden Sie hier:
Chrom

