

90 23 30 040 00



	Chrom	90 23 30 040 00-00
	Gold (23,9kt)	90 23 30 040 00-01
	chrom gebürstet (04)	90 23 30 040 00-04
	Platin gebürstet	90 23 30 040 00-06
	roh vernickelt	90 23 30 040 00-07
	Platin	90 23 30 040 00-08
	Messing (23kt Gold)	90 23 30 040 00-09
	schwarz	90 23 30 040 00-13
	Dark Brass matt	90 23 30 040 00-16
	Dark Bronze matt	90 23 30 040 00-17
	Dark Chrome	90 23 30 040 00-19
	Light Gold gebürstet	90 23 30 040 00-27
	Messing gebürstet (23kt Gold)	90 23 30 040 00-28
	Schwarz matt	90 23 30 040 00-33
	Dark Brass gebürstet	90 23 30 040 00-39
	chrom satin	90 23 30 040 00-41
	Bronze gebürstet	90 23 30 040 00-42
	Champagne gebürstet (22kt Gold)	90 23 30 040 00-46
	Champagne (22kt Gold)	90 23 30 040 00-47
	Cyprum	90 23 30 040 00-49
	Chrom gebürstet	90 23 30 040 00-93
	Dark Platinum gebürstet	90 23 30 040 00-99



Verschraubung - Chrom

ERSATZTEILE

90 23 30 040 00



Verschraubung - Chrom

ERSATZTEILE

90 23 30 040 00