

90 24 04 048 00



|                                                                                     |                                 |                    |
|-------------------------------------------------------------------------------------|---------------------------------|--------------------|
|    | Champagne (22kt Gold)           | 90 24 04 048 00-47 |
|    | Chrom                           | 90 24 04 048 00-00 |
|    | chrom gebürstet (04)            | 90 24 04 048 00-04 |
|    | Platin gebürstet                | 90 24 04 048 00-06 |
|    | Platin                          | 90 24 04 048 00-08 |
|    | Messing (23kt Gold)             | 90 24 04 048 00-09 |
|    | Weiß matt                       | 90 24 04 048 00-10 |
|    | Dark Chrome                     | 90 24 04 048 00-19 |
|    | Light Gold gebürstet            | 90 24 04 048 00-27 |
|   | Messing gebürstet (23kt Gold)   | 90 24 04 048 00-28 |
|  | Schwarz matt                    | 90 24 04 048 00-33 |
|  | Dark Brass gebürstet            | 90 24 04 048 00-39 |
|  | Bronze gebürstet                | 90 24 04 048 00-42 |
|  | Champagne gebürstet (22kt Gold) | 90 24 04 048 00-46 |
|  | Cyprum                          | 90 24 04 048 00-49 |
|  | Chrom gebürstet                 | 90 24 04 048 00-93 |
|  | Dark Platinum gebürstet         | 90 24 04 048 00-99 |



## Nippel - Champagne (22kt Gold)

ERSATZTEILE

90 24 04 048 00



## Nippel - Champagne (22kt Gold)

ERSATZTEILE

90 24 04 048 00