

Rosette - Platin

ERSATZTEILE

90 27 22 004 00



	Platin	90 27 22 004 00-08
	Chrom	90 27 22 004 00-00
	chrom gebürstet (04)	90 27 22 004 00-04
	Platin gebürstet	90 27 22 004 00-06
	Messing (23kt Gold)	90 27 22 004 00-09
	weiß	90 27 22 004 00-12
	schwarz	90 27 22 004 00-13
	Gold gebürstet (23,9kt)	90 27 22 004 00-14
	Messing gebürstet (23kt Gold)	90 27 22 004 00-28
	Rot	90 27 22 004 00-29
	Schwarz matt	90 27 22 004 00-33
	Platin / Platin gebürstet	90 27 22 004 00-36
	chrom satin	90 27 22 004 00-41
	Cyprum	90 27 22 004 00-49



Rosette - Platin

ERSATZTEILE

90 27 22 004 00



Rosette - Platin

ERSATZTEILE

90 27 22 004 00