














90 27 80 021 00



|   |                                 |                    |
|---|---------------------------------|--------------------|
|    | Chrom                           | 90 27 80 021 00-00 |
|    | Platin gebürstet                | 90 27 80 021 00-06 |
|    | Platin                          | 90 27 80 021 00-08 |
|    | Dark Brass matt                 | 90 27 80 021 00-16 |
|    | Dark Bronze matt                | 90 27 80 021 00-17 |
|    | Dark Chrome                     | 90 27 80 021 00-19 |
|    | Light Gold gebürstet            | 90 27 80 021 00-27 |
|    | Messing gebürstet (23kt Gold)   | 90 27 80 021 00-28 |
|    | Dark Brass gebürstet            | 90 27 80 021 00-39 |
|   | Bronze gebürstet                | 90 27 80 021 00-42 |
|  | Champagne gebürstet (22kt Gold) | 90 27 80 021 00-46 |
|  | Champagne (22kt Gold)           | 90 27 80 021 00-47 |
|  | Dark Platinum gebürstet         | 90 27 80 021 00-99 |



Rosette Ø 60 x 18 mm - Chrom

ERSATZTEILE

---

90 27 80 021 00



Rosette Ø 60 x 18 mm - Chrom

ERSATZTEILE

90 27 80 021 00