


















90 28 22 538 04



	Platin	90 28 22 538 04-08
	Chrom	90 28 22 538 04-00
	Gold (23,9kt)	90 28 22 538 04-01
	chrom gebürstet (04)	90 28 22 538 04-04
	chrom edelmatt	90 28 22 538 04-05
	Platin gebürstet	90 28 22 538 04-06
	Messing (23kt Gold)	90 28 22 538 04-09
	Weiß matt	90 28 22 538 04-10
	weiß	90 28 22 538 04-12
	schwarz	90 28 22 538 04-13
	Gold gebürstet (23,9kt)	90 28 22 538 04-14
	rot (15)	90 28 22 538 04-15
	Rot	90 28 22 538 04-29
	Schwarz matt	90 28 22 538 04-33
	Platin / Platin gebürstet	90 28 22 538 04-36
	aluminium (45)	90 28 22 538 04-45
	cyprum matt	90 28 22 538 04-56



Bürstengriff Ø 25 x 296 mm - Platin

ERSATZTEILE

90 28 22 538 04



Bürstengriff Ø 25 x 296 mm - Platin

ERSATZTEILE

90 28 22 538 04

90 28 22 538 04

Ersatzteile für die
anderen
Oberflächenvarianten
finden Sie hier:
Chrom

