



Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /  
Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat /  
Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /  
Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Pieze de schimb  
/ Rendelhető alkatrészek / Запасні частини / Reservni delovi / Резервни делови /  
Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daļu




Ideal Standard

JOY



BC 805 ..

1119 / A 868 629




XX = AA, GN, ...





Pos.	Part No.
1	A 861 437 NU
2	A 861 438 XX
3	A 861 450 XX
4	A 962 002 NU



Ideal Standard International NV  
Corporate Village - Gent Building  
Da Vincilaan 2  
1935 Zaventem  
Belgium

[www.idealstandardinternational.com](http://www.idealstandardinternational.com)





	<b>P</b>	<b>bar</b>	MIN. 0,5		MAX. 5	<b>Q</b> (3 bar)
	<b>T</b>	<b>°C</b>	MIN. 10		MAX. 80	<b>l/min</b>
						<b>??</b>